


GETTING STARTED

Image Sensor


The Image Sensor is a unique device that detects motion, and shows it. It's also easy to set up in just a few quick steps:

- 1 Select a spot about 6 feet off of the ground in a central, high-traffic area of your home.
- 2 If you're adhering your Image Sensor to a wall, make sure the surface area is clean and dry. *(Note: You can also set the sensor on a shelf. If you wish to do so, remove the mounting bracket.)*
- 3 Remove the wax backing, press the sensor firmly against the wall for 30 seconds.
- 4 Ensure that the sensor is aimed at the area you wish to cover.

This is best achieved by placing the sensor across the room from the door or entry point.



Placement view from the Image Sensor facing the appropriate door



The Image Sensor has a detection range of 90 degrees, and detects motion up to 35 feet away